

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.

DANGER TO REDUCE THE RISK OF ELECTRIC SHOCK:

1. Always unplug this furnishing from the electrical outlet before cleaning.

WARNING TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Do not use outdoors.
7. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
8. During lamp replacement, do not touch the bulb unless it has fully cooled.

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS:

“To reduce the risk of electric shock, this furnishing has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.”

SAFETY NOTES:

1. This is not a toy; keep out of reach of children and pets.
2. Always turn off product when leaving the house or before bed. Never leave unattended.
3. Do not expose to moisture or use in a wet or damp environment.
4. Never touch electrical items with wet hands.
5. To avoid strain or damage to the eyes, avoid prolonged viewing when product is in operation.

OPERATION:

1. Place Disco ball on a solid stationary surface.
2. Disco ball rotates 360° on base. It can turn either clockwise or counter-clockwise.
3. Replace only with a bulb of the specified rating as indicated on the lamp holder.
4. Plug in & ENJOY!


Note: Using the wrong wattage, size or type of bulb could cause a fire.

CLEANING:


Do not use polish or cleaners. Wipe clean with a soft, dry cloth as needed.

TO REPLACE THE BULB:

Always unplug unit from the power source.

- 
- ← Rotate ball counter-clockwise.
 - ← Hold the stem on base.
 - ← Replace bulb as rated on label.

Note: To replace depleted bulb, use max. 15W, 120V, E12, T7 type bulb.



LIMITED 90 DAY WARRANTY

This unit is warranted by **LIFESPAN BRANDS LLC** against defects in workmanship or materials for 90 days from the date of purchase. The duration of any express or implied warranties, including implied warranties of merchantability or fitness for a particular purpose, are limited to 90 days from the date of purchase. This warranty shall be void if the unit has been subject to abuse, negligent handling, and disregard of operating instructions or attempted repair by anyone other than the manufacturer.

LIFESPAN BRANDS LLC shall in no event be responsible for incidental or consequential damages of any nature or amount. **NOTE:** Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you (as the purchaser) may also have other rights which vary from state to state.

SERVICE AND REPLACEMENT INSTRUCTIONS

Within the 90 day warranty period, if for any reason your unit does not function properly, **please return it to the retailer where the purchase was made.** The manufacturer is the only one that can make warranty replacements after 90 days. **DO NOT RETURN THE PRODUCT TO LIFESPAN BRANDS LLC UNLESS AUTHORIZED BY A COMPANY REPRESENTATIVE.** Customer service may be contacted at 1-800-336-5282 or via email at orders@lavalite.com.

For a complete listing of all LAVA® brand products, please visit us at www.lavalamp.com.